



Installation Instructions:

There are several options you can use to install your Kerb Marker.

1. Using a Nylon Anchor or “Tappit” – for permanent fixing
2. Using a “Rawl Plugs and Stainless Steel Screws” – allows the number to be changed easily
eg for a “Reserved” car park, with a ”Name” (“THE BOSS”) or “Rego (CME L8R)
3. Using “Stainless Steel Screws” – to mount onto Timber or Wood. - NB: Square Drive screws are used to minimize them from being removed easily.

Any problems please contact us.

Telephone: 027 433 6054

Email: sales@kerbmarkers.co.nz